


Installation Instructions TH-1040-RCA

Raked Ceiling Accessory For TH-1040-CTS and TH-1040-CTL

Components Checklist





Tools Required:

- Power Drill
- 7mm (0.25") drill bit
- 12mm (0.5") masonry drill bit
- 17mm (0.69") Socket Wrench or Shifter


IMPORTANT INFORMATION

- ! IMPORTANT Install 1040 Raked Ceiling Accessory as per Installation Instructions.
- ! This product is to be installed in conjuction with TH-1040-CTS and TH-1040-CTL Ceiling Mounts only.
- ! Supports maximum angle of 45°.
- ! The manufacturer does not accept responsibility for incorrect installation.


Step 1. Check Components

Check you have received all parts against the component checklist and Hardware above.


Step 2. Mount Ceiling Adapter to Ceiling using hardware supplied with TH-1040-CTS/TH-1040-CTL



Step 3. Install Pole



Step 4. Adjust Angle



Installation Complete, continue with installation of TH-1040-CTS/TH-1040-CTL from Step. 6 onwards.